



Crankshaft Assembly




Pull Start Assembly




*Part 5211R (roller clutch) not included with complete starter assembly packages.


Air Filter Assembly



Exhaust Assembly



EZ-Start™ 2 Assembly



5270 Complete EZ-Start™ System.
Includes drive unit, controller
and wiring harness.

*Part 5211R (roller clutch) not included with complete starter assembly packages.